**Fig. 1**

Fig. 2A

30 →






Fig. 2B

30 →




**3D Card
Directions**
Remove 3D card at
perforation. Place into
the 3D-100 Viewer with
the blue stripe away
from eyes.

STAMP



3D Card Magazine Ad Insert



CD. Internet Digital Source








Fig. 5


**Fig. 6****Fig. 7**







"Bulk Style" Family Activity Set Clamshell
Fig. 8



Shipper/Display Box
Fig. 9

**Fig. 10**



**Fig. 12A****Fig. 12B****Fig. 13**




Fig. 14A




Fig. 14B




Fig. 14C

